

Helpful Hints in Fitting your Suzuki SJ Series Soft Top



1. Place the soft top over the rear hoop. Pull forwards to reach the front window ready for step 2.
2. Ensure that the soft top is aligned centrally at this stage.
3. Fit the front section by pushing from one side to the other through the grooved channel fitted to your windscreen. (see [Suzuki SJ Series Front Strip Fitting](#) to understand more clearly).
4. Slide the side section into the vertical channels behind the roll bar.
5. Fit the durables on each side of the Rear Corners. First the side and then the rear positions.
6. Attach the wraparounds on the rear and side hoop.*
7. Fit the remaining durables on each side.
8. Fit the Lift the Dot fastenings on the rear window section to the fittings on the Tailgate.
9. Fit the flaps around the door posts.
10. Fitting Complete.

*** If you do not have the durables fitted to your rear hoop that correspond with the fitting in your Monsoon soft top, don't panic!**

They are not a necessity, and not all SJ's have them. However, you can purchase extra durables so that you can fit them to the rear hoop yourself.